## User Machine Interfaces

Two types of User-Machine Interfaces (UMI) are available for Sepam series 60 base units:
- Mimic-based UMI
- Advanced UMI.

The advanced UMI can be integrated in the base unit or installed remotely on the cubicle. Integrated and remote advanced UMIs offer the same functions.

Integrated mimic-based UMI	Integrated advanced UMI	Remote advanced UMI

Sepam series 60 base unit